

RC15 PACKAGED TERMINAL AIR CONDITIONER REPLACEMENT FOR:

American Standard Series 41, American Air Filter Series 25 & Others

STRAIGHT COOL

Nominal Capacities:
9,000 - 12,000 - 15,000
& 18,000 Btuh

RETROAIRE

The Right Fit for Comfort



BC15



RC15



CC15

Enviromaster International LLC
5780 Success Dr.
Rome, NY 13440
Phone: 1-800-228-9364
Fax: 1-800-232-9364
Email: info@retroaire.com

An **ECR** International Brand
An ISO 9001-2000 Certified Company



RC15 STRAIGHT COOL PACKAGED TERMINAL AIR CONDITIONER

INSTALLATION, OPERATION & MAINTENANCE GUIDE

P/N# 240000666, Rev. 1.3 [02/05]

Shipping Damage MUST be Reported to the Carrier IMMEDIATELY!!!
Examine the exterior. Remove cover and examine compressor and piping for signs of damage.

This manual is intended as an aid to qualified service personnel for proper installation, operation, and maintenance of the RetroAire RC15 Packaged Terminal Air Conditioner (PTAC). Read these instructions thoroughly and carefully before attempting installation or operation. Failure to follow these instructions may result in improper installation, operation, service, or maintenance, possibly resulting in fire, electrical shock, property damage, personal injury, or death.

TO THE INSTALLER

- (1) Retain this manual and warranty for future reference.
- (2) Before leaving the premises, review this manual to be sure the unit has been installed correctly and run the unit for one complete cycle to make sure it functions properly.

To obtain technical service or warranty assistance during or after the installation of this unit, contact your local representative. Visit our website www.retroaire.com for a local representative listing. For further assistance call 1-800-228-9364.

When calling for assistance, please have the following information ready:

- Model Number _____
- Serial Number _____
- Date of installation _____

 **Recognize this symbol as an indication of important safety information** 

SAFETY INSTRUCTIONS

- ▲ Read all instructions before using the RetroAire RC15 PTAC. Install or locate this unit only in accordance with these instructions. Use this unit only for its intended use as described in this manual.
- ▲ Check the rating plate on the RetroAire RC15 PTAC before installation to make certain the voltage shown is the same as the electric supply to the unit.
- ▲ The RetroAire RC15 PTAC must be connected only to a properly grounded electrical supply. Do not fail to properly ground this unit.
- ▲ Turn off the electrical supply before servicing the RetroAire RC15 PTAC.
- ▲ Do not use the RetroAire RC15 PTAC if it has damaged wiring, is not working properly, or has been damaged or dropped.

[Save These Instructions]

DANGER

The RetroAire PTAC must:

- ▲ Be connected to a properly grounded electrical supply with the proper voltage as stated on the rating plate.
- ▲ Have proper over current protection (i.e. time-delay fuse/HACR-Breaker) as listed on the Rating Plate.

Failure to follow these instructions can result in a fire, explosion, or electrical shock causing property damage, personal injury, or death.

TABLE OF CONTENTS

To the Installer and Safety Instructions	2
Warnings and Installer Responsibilities	3
Controls and Components	4
Product Description, Capacities, Air System	4
Heat-exchanger, Refrigeration, Electrical Wiring	4
Installation Instructions	5-6
Final Inspection and Start-Up	7
Sequence of Operation	8-9
Cleaning and Maintenance	10
Troubleshooting	10
Specifications and Dimensions	11
Warranty	12

INSTALLER RESPONSIBILITIES

This manual has been prepared to acquaint you with the installation, operation and maintenance of this RetroAire RC15 PTAC and to provide important safety information in these areas.

We urge you to read all of the instructions thoroughly before attempting the installation or operation of this unit. This manual should be kept for future reference.

The manufacturer of this unit will not be liable for any damages caused by failure to comply with the installation and operating instructions outlined in this manual.

A rating plate identifying this RetroAire RC15 PTAC can be found on the unit. When referring to your unit, always have the information listed on the rating plate readily available.

MODIFICATION AND TAMPERING



Tampering with the RetroAire RC15 PTAC is dangerous and may result in serious injury or death. Tampering voids all warranties. Do not attempt to modify or change this unit in any way.

IMPORTANT SAFETY FEATURE

Power Cord With Integral Safety Protection

All PTACs rated 250V or less that are cord connected to the power supply are equipped with a power cord with integral safety protection as standard. Providing personal shock protection as well as arcing and fire prevention, the device is designed to sense any damage in the line cord and disconnect power before a fire can occur. Tested in accordance with Underwriters Laboratories, the cord set also offers a unique "passive" operation, meaning the unit does not require resetting if main power is interrupted.

WARNING - A DAMAGED POWER SUPPLY CORD MUST BE REPLACED WITH A NEW CORD FROM THE MANUFACTURER, AND NOT REPAIRED.

Each power cord should be checked before every use. Follow the instructions in the order listed on the device.

WARNING - DO NOT USE THE PRODUCT IF THE UNIT FAILS THE TEST.



Completely read all instructions prior to assembling, installing, operating, or repairing this product. Inspect all parts for damage prior to installation and start-up. The RetroAire RC15 PTAC must be installed ONLY by qualified installation personnel.

PRODUCT DESCRIPTION

The RetroAire RC15 replacement chassis is a cooling-only model conditioner designed to allow owners of American Standard Series 41, American Air Filter Series 25 and other packaged terminal units to upgrade room comfort while reducing operating costs through higher efficiency and enhanced reliability.

Energy efficiency ratings are as high as 10.0 E.E.R., which can mean rapid payback of your replacement investment through energy savings. The RetroAire RC15 features two fan speeds. Its separate outdoor fan does not run in venting or heating modes, thereby saving energy.

Whisper-quiet operation improves the room ambiance and a washable, permanent filter makes service a snap. The 20 gauge G-90U, galvanized steel construction of the chassis ensures long service life.

All RetroAire products are backed by EMI and ECR International and are tested and rated in accordance with ARI Standards 310 & 380 and UL 484. A full service parts inventory is always available.

CAPACITIES

The RC15 Replacement Chassis are available in nominal capacities of 9,000, 12,000, 15,000, and 18,000 Btuh.

AIR SYSTEMS

- Fans are forward-curved type, directly mounted to the motor shafts.
- Motors are PSC type with overheat protection.
- Air-stream surfaces are insulated with ¼" fiberglass.
- Filter is permanent, washable, and accessible without tools.

HIGH EFFICIENCY HEAT EXCHANGER

Coil is seamless, rifled copper tubing, arranged in staggered configuration, with enhanced aluminum fins, tested to 460 psig. The tubes are mechanically expanded for secure bonding to fin shoulders.

REFRIGERATION CIRCUIT

- High efficiency, rotary compressor with a five-year warranty standard.
- Automatic expansion valve refrigerant metering for low-ambient protection.

STANDARD FEATURES AND ACCESSORIES

- The RC15 units are designed to fit both the existing wall sleeve and cabinet of the old unit, but when either the sleeve or cabinet must be replaced because of rust or damage, RetroAire can supply custom replacements.
- Motorized fresh air damper with positive-pressure seal and override switch.
- Continuous/cycling fan control switch.
- Electric heat at 3, 4, or 5 KW.
- Hydronic Heat.
- Normally/open normally/closed motor valve-switch, hydronic heat only.

A Note On Wall Thickness

The distance from the condenser coil to the outdoor louver varies with sleeve depth. Each chassis includes two 1³/₈" or zero clearance air baffles to accommodate most common condenser coils to outdoor louver requirements. In addition, we stock an optional condenser-side air baffle kit for chassis installation in deeper than standard wall sleeves. The kit is a two-piece sliding design.

ELECTRICAL WIRING

IMPORTANT: *Make sure the motor valve is rated for the correct voltage. Most RetroAire units with unit mount controls will power a normally closed valve that is the same voltage as the unit (ex: a unit rated 208/230V will power a 208/230V normally closed valve). Be sure to check the wiring diagram (located on the unit) and voltage application for the specific unit. Other valve configurations and voltage options are available. Consult Technical Service if the unit voltage does not match your valve application.*

1. Inspect existing wiring for any deficiencies such as cut or frayed wires.
2. All electrical wiring must be run according to NEC and local codes. Check the unit rating plate for circuit ampacity and breaker or fuse size. Use only HACR type breakers & select the proper wire for the ampacity rating.
3. If plug and receptacle are used, check for proper fit.

INSTALLATION INSTRUCTIONS

RC15 INSTALLATION KIT

- 1 Installation Manual
- 1 Condenser Baffle
- 4 #8x3/8 Screws
- 4 #8x1/2 Screws
- 2 Thermostat Bulb Clips
- 2 Thermostat Bulb Clips Grommets
- 1 13"x22" #20 Porevel Filter
- 1" x 1" Open-cell Foam Tape
- 2 Condensor Baffles
- 2 Extension Baffles
- 2 Side Baffles
- 1 Top Baffles
- 4 Crimp Popcorn (Medium)

HYDRONIC ONLY


- 1ea. 2-Position Connector & Pin Mate
- 14AWG Yellow Wire
- 2 Crimp Popcorn (Medium)

BC15 INSTALLATION KIT

- 4 #8x1/2 Screws
- 1" x 1/2" Open-cell Foam Tape
- 2 Blower Section Support Clips

1. Disconnect power to the cooling chassis.
2. Remove chassis from wall sleeve.
3. Remove existing screws that mount the blower deck, slide out existing blower deck, and replace with new blower deck (BC15), attach by re-using existing screws. [Figure 1]
4. Remove existing control box from side of blower enclosure. Place new control box (CC15) on right hand side of blower enclosure, and attach using existing screw holes and hardware. [Figure 1]

Figure 1




IMPORTANT: The correct condenser air baffles must be installed or performances may be impaired and/or the warranty will be voided.

5. Verify that the correct condenser baffles are being utilized. [Figure 2]


NOTE: Baffles should either butt against the back-side of the condenser louver or be within 3/8" from the raw edge of the condenser baffle to the backside of the condenser louver.

6. 3 sets of baffles are included in the kit bag shipped along with the unit [Figure 2], be sure to install the baffles for proper air flow and efficiency.

Figure 2



7. Ensure proper foam tape gaskets are used [Figure 3].
8. Install cooling chassis by sliding it into the wall sleeve, once in place; ensure there are not any air by passes on the evaporator side.




9. Connect molex connectors from chassis, blower and control box. Each molex connector is individually labeled to prevent mismatching. Make sure the label on the plugs matches the label on the mating sockets exactly. [See wiring diagram on unit] and [Figure 4].
10. Install the cooling chassis. Look at the slide rails (note that they are set in horizontally on the cooling chassis and wall sleeve sides). Slide cooling chassis into place. [Figure 4]

11. Plug line cords into receptacles.

Note: Check rating plate voltage and amperage/fuse size for proper supply.

12. To install thermostat bulb to coil.
 - Remove air filter from coil.
 - Take the thermostat bulb clips and grommets out of the baffle kit bag.
 - Slide grommets into clips.
 - Install on the middle of the evaporator coil by pressing the round part of the clips through the coil fins.
 - Once this is done, position thermostat bulb into clips.
 - Replace air filter. [Figure 4]
13. Turn power on.
14. Check for proper operation (cooling, fresh air, and heating (if supplied)).



CAUTION


When the unit is first powered up, high humidity conditions can cause condensation to form on the discharge grill. Keep doors and windows closed to reduce humidity and condensation will evaporate.

1. Make sure the chassis is level. Check by pouring water into the drain pan and making certain it flows through the drain hoses to the condenser side of the unit.
2. Plug or hard wire line voltage to unit.


IMPORTANT: Follow the information provided on the rating plate for voltage and amperage/fuse size for proper supply.

3. Attach the front panel to the existing cabinet enclosure.
4. Turn the power on.
5. Check for proper operation (i.e., cooling, optional fresh air, and heating if supplied).
6. Check to be sure nothing will interfere with the room discharge air or the return air to the units (i.e., curtains or drapes that obstruct the air flow or plush carpeting that can obstruct the return air (see below)). Items like these can cause serious damage to the chassis and can void the warranty.

The position of curtains or drapes over supply air grille may cause air to recirculate without cooling the room. The unit will short cycle and may cause premature compressor failure.



NOTE: Any obstruction of supply air including the use of deflector baffles, may cause condensate to form on the louver or cabinet.



To ensure optimum performance of your PTAC, avoid restricting the air flow.

SEQUENCE OF OPERATION

UNIT MOUNTED AND REMOTE THERMOSTAT CONTROLS: RetroAire units can be equipped with unit mounted or remote controlled thermostats. Turning the unit mounted thermostat knob to the far left will produce the warmest room temperature while turning it all the way to the right will produce the coolest. These settings can be adjusted for personal comfort.

⚠ CAUTION ⚠

Avoid rotating the thermostat knob back and forth from heating to cooling. This causes the compressor to cycle on and off rapidly and **WILL** cause damage to the compressor. Allow the compressor to remain off for at least three minutes prior to restarting the unit.

COOLING CYCLE

1. Place system switch in the “COOL” position.
2. Rotate thermostat knob (*Figure A*) clockwise until the compressor fans start running and cold air begins to flow from the unit. For a colder room temperature, continue turning the thermostat knob clockwise and let the unit continue operating to cool the room and remove humidity. If a warmer room temperature is desired, rotate the thermostat knob counter-clockwise until the compressor cycles off.


IMPORTANT: *The room temperature must be above 65° F for the compressor to operate.*

3. Place system switch in the “OFF” position. All operation should stop.

HEATING CYCLE - ELECTRIC

1. Place system switch in the “HEAT” position.
2. Rotate thermostat knob counter-clockwise until the indoor fans start running and the electric coil starts emitting heat. The condenser fans do not run during the heating cycle unless the chassis is a heat pump. After the unit starts running and the area gets warmer, turn the thermostat knob clockwise until a slight click is heard and the electric heater turns off. If a warmer room temperature is desired, continue turning the knob counter-clockwise and let the unit continue operating. If a cooler room temperature is desired, rotate the thermostat knob clockwise until the electric heater cycles off.

Figure A



IMPORTANT: *Room temperature must be below 85° F to energize the heater.*

3. Place system switch in the “OFF” position. All operation should stop.

HYDRONIC COIL: The coil with the old unit can be located in the subbase, under the chassis in a special attachment, or above the chassis in a special attachment. It is necessary to know where the coil is to be located and the physical size of the coil so the right coil can be supplied if ordered for replacement. The coil is shipped loose for field installation. It should be installed in the same manner as the coil it is replacing. When the hydronic coil is not replaced, installation of the chassis should follow the instructions in this manual.

HEATING CYCLE - HYDRONIC: All straight cool Dual Motor PTACs are equipped with a field supplied hydronic heat option. The unit is provided with a two-position molex plug for motor valve connection. To wire this option, take the molex plug connector with (2) yellow wires from the kit and plug it into the molex on the unit. Then wire the opposite end of the molex to the motorized valve in the hydronic circuit.

IMPORTANT: *Make sure the motor valve is rated for the correct voltage. Most RetroAire units with unit mount controls will power a normally closed valve that is the same voltage as the unit (ex: a unit rated 208/230V will power a 208/230V normally closed valve). Be sure to check the wiring diagram (located on the unit) and voltage application for the specific unit. Other valve configurations and voltage options are available. Consult Technical Service if the unit voltage does not match your valve application.*

- A. Place system switch in the "HEAT" position.
- B. Turn thermostat knob counter-clockwise. Motorized valve should open and allow hot water to run through the coil. the indoor fans will run, blowing air through the hydronic coil.
- C. Check room comfort level as outlined under "Heating Cycle - Electric."

MOTORIZED FRESH AIR DAMPER (OPTIONAL): The optional motorized fresh air damper allows the operator to move fresh air into the space to be conditioned. This is done by placing the damper door switch in the "YES" position, opening the damper door and allowing fresh air to be moved into the space. To stop the flow of fresh air, simply place the switch in the "NO" position.

CHANGEOVER T-STATS (HEAT PUMP ONLY): On units with a changeover thermostat, the compressor can run to an outdoor temperature of 40° F and then shut off. Electric heat will then energize and assume the heating demand until the temperature of the outdoor air rises to approximately 50° F.

FAN CYCLE SWITCH: This option allows the operator of the Dual Motor PTAC to have the evaporator fan cycle or run continuously. With the switch in the cycling position the evaporator fan will only run when the unit is calling for heat or cooling. When the switch is in the "CONSTANT" position, the evaporator fan will run continuously unless the unit is physically turned off.

CONDENSATE REMOVAL: The Dual Motor PTAC has a drain connection at each end of the condensate drain pan. This allows the condensate to drain through the bulkhead to the area near the condenser fan. The condenser fan has a slinger ring that picks up the condensate and slings it on the hot condenser coil where it evaporates. On heat pump models condensate can form on the outdoor coil during the heat pump cycle. A temperature sensitive valve in the base pan will allow condensate to flow to an internal piping system or external drain kit (supplied by others).

AQUASTAT CONNECTION (OPTIONAL): All straight cool Dual Motor PTACs are supplied with a standard high volt aquastat connection. The connection is located on the bottom or side with a black jumper wire installed in molex. To wire option take jumper wire and cut in half. Then connect 2 field supplied wires to the cut ends of jumper and wire to aquastat (see wiring diagram for more information). If option is not being used simply leave jumper wire connected to unit.

CLEANING AND MAINTENANCE

DANGER

Before servicing the RetroAire Dual Motor PTAC, be sure to turn off electrical power to the unit. Failure to do so can result in a fire, explosion or electrical shock causing property damage, personal injury or death.

WARNING

It is illegal to discharge refrigerant into the atmosphere. Use proper reclaiming methods and equipment when servicing a RetroAire Dual Motor PTAC.

CLEANING THE INTERIOR OF THE UNIT

1. Disconnect power from unit.
2. Remove access panels and do a visual inspection of the unit, making sure to check for obvious problems such as damaged coils or evidence of extended wear on any moving part.
3. Check for unusual odors, oil leaks, or stains on or around the coil and refrigerant lines. The presence of oil here may indicate a potentially serious problem such as a refrigerant leak.
4. Inspect all electrical connections. Look for frayed wires and poor connections. Terminal ends that are loose will eventually fail, causing a loss of performance or worse.
5. Check fan motors and blower assemblies. Some units may require a drop of light oil to motors and/or bearing assemblies (look for oil cups). Check set-screws and motor mounting hardware, making sure they are tight.
6. Brush and/or vacuum the centrifugal fan blades and blower cage assemblies. These parts must be clean to operate efficiently.
7. Inspect and clean the indoor and outdoor coils, using a fin comb, if necessary, to straighten any damaged fins. these coils must be clean for proper operation.

IMPORTANT: Do not use a solvent-based cleaner on the indoor or outdoor coils. Some solvents can produce a noxious odor when starting the fan or electric heat.

8. Inspect and clean the drain pan and drainline (if any). Use of an anti-fungicide tablet is recommended to keep the condensate system free from bacterial contaminants.

9. Check weep holes along the rear flange of the base pan, making sure they are open.
10. Check the pitch of the unit. Over time the building and equipment may settle, causing a shift in the direction of the condensate flows. Ideally the unit should pitch a minimum of 5° (at least 1/2") to the outside to allow for proper drainage.
11. Replace panels and reconnect electrical power.
12. Test unit operation.

CLEANING THE EXTERIOR

1. Clean the air filter at least once a month by removing it from the unit and washing or vacuuming any dust from its surface. Allowing dust to collect on the filter will cause the PTAC to lose efficiency and eventually malfunction.
2. When cleaning the filter, be sure to vacuum any dust from the return air grille surface as well.
3. Clean exterior of the cabinet as desired with a mild soap or household cleaner.

IMPORTANT: If a new air filter is needed for your RetroAire Dual Motor PTAC, consult factory for availability and/or proper sizing.

TROUBLESHOOTING


- If the compressor will not start, check to see if the thermostat is satisfied. If the thermostat is not satisfied, check for proper wiring and make sure that relays are not damaged.
- If there is no electric heat, see if heater contacts pull in. Possible problems could be the heat relay, limit switch, or fuse link.
- If you are unable to find any of these problems, contact the factory for further information.

NOTE: CR/relay = cooling relay
HR/relay = heating relay

RC15 SPECIFICATIONS AND DIMENSIONS

IMPORTANT: Due to RetroAire's on going development programs, designs and specifications may change without notice. Please consult factory for the latest information and submittal data before making any job site updates.

Dimensions



RC15 Hydronic Heat Performance 104-156 (Single Row Coil)			
GPM	EWT (°F)	Capacities	P.D. ftWC
3.0	180°F Hi	24,880	9.5'
	180°F Lo	23,330	9.5'
	140°F Hi	15,750	10'
	140°F Lo	14,770	10'

RC15 Optional Electric Heat Specifications								
Heater No.	Voltage	Watts	Btuh	Amps	Total Heat Amps	MCA	Max Fuse	Line Cord
3	208	2,454	8,400	11.8	12.4	15.3	20	6-20P
	230	3,000	10,300	13	13.6	16.9	20	6-20P
	265	3,983	13,600	15	15.7	19.5	20	7-20P
4	208	3,271	11,200	15.7	16.3	20.3	25	6-30P
	230	4,000	13,700	17.4	18	22.3	25	6-30P
	265	5,310	18,200	20	20.7	25.7	30	7-30P
5	208	4,089	14,000	19.7	20.3	25.2	30	6-30P
	230	5,000	17,100	21.7	22.3	27.8	30	6-30P

RC15 Electrical Specifications												
Model Number	Voltage/Hz/Phase	Evap Motor		Cond Motor		Compressor		Total Amps	MCA	Max Fuse	Min Voltage	Line Cord
		FLA	HP	FLA	HP	RLA	LRA					
9	208/230/60/1	0.6	0.08	0.71	0.09	3.8	20	5.1	6.1	15	197	6-15P
	265/60/1	0.67	0.08	0.71	0.09	3.3	18.6	4.7	5.5	15	240	7-20P
12	208/230/60/1	0.6	0.08	0.71	0.09	4.8	26.3	6.1	7.3	15	197	6-15P
	265/60/1	0.67	0.08	0.71	0.09	4.2	28	5.6	6.6	15	240	7-20P
15	208/230/60/1	0.6	0.08	0.71	0.09	6.4	38	7.7	9.3	15	197	6-15P
	265/60/1	0.67	0.08	0.71	0.09	5.4	32	6.8	8.1	15	240	7-20P
18	208/230/60/1	0.6	0.08	0.71	0.09	7.6	45	8.9	10.8	15	197	6-15P
	265/60/1	0.67	0.08	0.71	0.09	6.3	32	7.7	9.3	15	240	7-20P

NEMA Specifications Non-Locking/Receptacles									
VOLTAGE	125V			250V			265V		
	15(A)	20(A)		15(A)	20(A)	30(A)	15(A)	20(A)	30(A)
PLUG									
RECEPTACLE	5-15 R	5-20 R		6-15 R	6-20 R	6-30 R	7-15 R	7-20 R	7-30 R

ALL PRODUCT LIMITED WARRANTY

Enviromaster International Corporation LLC (EMI) warrants to the purchaser/owner, that the EMI products will be free from defects in material and workmanship under the normal use and maintenance for a period of twelve months for all components, and (60) months on unit compressors from date of the original installation or 15 months for all components and 63 months on unit compressors from the date of original sale whichever comes first.

WHAT WE WILL COVER

EMI will replace any defective part returned to EMI's approved service organization with a new or rebuilt part at no charge. The replacement part assumes that unused portion of this warranty.

WHAT WE DON'T COVER

THIS WARRANTY DOES NOT INCLUDE LABOR or other costs incurred for repairing, removing, installing, shipping, servicing, or handling of either defective or replacement parts.

EMI IS NOT RESPONSIBLE FOR

- Normal maintenance
- Damage or repairs required as a consequence of faulty installation or application by others.
- Failure to start due to voltage conditions, blown fuses, open circuit breakers, or other damages due to the inadequacy or interruption of electrical service.
- Damage or repairs needed as a consequence of any misapplication, abuse, improper servicing, unauthorized alteration, or improper operation.
- Damage as a result of floods, winds, fires, lightning, accidents, corrosive atmosphere, or other conditions beyond the control of EMI.
- Parts not supplied or designated by EMI.
- Products installed outside the United States or Canada.
- Any damages to person or property of whatever kind, direct or indirect, special or consequential, whether resulting from use or loss of use of the product.

LIMITATION OF WARRANTIES

This Warranty is exclusive and in lieu of any implied warranties of merchantability and fitness for a particular purpose and all other warranties express or implied. The remedies provided for in this warranty are exclusive and shall constitute the only liabilities on the part of EMI including any statements made by any individual which shall be of no effect.

FOR SERVICE OR REPAIR:

- 1) Contact the installer _____
- 2) Call the nearest distributor _____
- 3) Call or write _____


An **ECR International Brand**
ENVIROMASTER INTERNATIONAL LLC
5780 Success Dr., Rome, NY 13440
Phone: 1-800-228-9364
FAX: 1-800-232-9364
Email: info@retroaire.com